

NorConcertControl Webdisplay configuration

To configure NorConcertControl Webdisplay, open *webroot/php/config.php* in a **text editor**.

The Config File

| | |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| \$dbName | Path to the Database File (NorConcertControl.mdb) |
| \$splFile | Path to the temporary SPL file |
| \$updateRateInMilliseconds | Graph/Data refresh rate in milliseconds |
| \$splUpdateRateInMilliseconds | SPL refresh rate in milliseconds |
| \$useLanguageFromConcertControl | Whether to use the language set in NorConcertControl or the \$language config option. (true/false) |
| \$language | <p>The language in which NorConcertControl Webdisplay should be displayed, if \$useLanguageFromConcertControl is set to false.</p> <p>You can add a custom language by copying the file <i>webroot/locales/en.php</i> to <i>yourLanguage.php</i>. To edit the language file just open it in a text editor and translate the text behind the equal sign. (<code>\$lang['EXAMPLE'] = 'edit this';</code>)</p> <p>Then set \$language to <i>yourLanguage</i>.</p> |